

# MX CALLPOINT RESET PROCEDURE

Note the positions of the plate depending on whether the unit has been activated or not:



Not activated



Activated – note flex in plate and gap

To reset, insert key:



Turn key 90 degrees clockwise. This will disengage the plate. It will look slanted:



Keeping the key 90 degrees, push it back into the unit to set the plate back in position. While holding the key in, turn it back to the upright position. Remove the key.